PR = Predicate register
GPR = General-purpose register (integer or floating-point)

Figure 13.19 IA-64 Instruction Format